



Fabric Duct Systems, Inc.

Cleaning Instructions

300 denier Polyester & 1500 denier Polyethylene

Washing and cleaning of PowerThrust® fabric air diffusers should be carried out in accordance with the following instructions.

- 1.) Hand or power wash with clean water @ max. 140` F. Diffusers made of polyester may be machined washed.
- 2.) If the diffusers are heavily soiled, use mild laundry detergent in accordance with manufacturer's instructions.
- 3.) After washing, rinse with clean cold water.
- 4.) Do not dry in dryer, hang dry.

Because PowerThrust® diffusers are laundered so infrequently, extremely soiled diffusers will require laundering more than once. We suggest contacting a local industrial laundering service equipped with industrial laundering equipment to more thoroughly clean the diffusers.